

# Installation, Operations & Service Manual R-1130 Cobra Front Brake Kit

## **Installation Safety Precautions**

If any installation problems are encountered, please call G&B Specialties for technical assistance before continuing with the installation process.

| CAUTION VARNING | Read and understand this manual completely before attempting installation of the equipment.  |
|-----------------|--|
|                 | Installation instructions provided below only address the Rafna railgear equipment. Applicable railway company procedures and policies must be adhered to. |
|                 | Before performing any work under the vehicle or railgear, ensure the engine is turned off and the parking brake is set.                                    |
|                 | Beware of all pinch points on the railgear and keep all parts of the body clear.   |
|                 | Always disconnect the vehicle's battery when welding on the vehicle or railgear in order to protect the vehicle's electrical system.                       |



## TABLE OF CONTENTS

| 1.0   | General Information        |     |
|-------|----------------------------|-----|
|       | Front Brake Kit Components | 3   |
| 2.0   | Installation               | 4-5 |
| 3.0   | Adjustment                 | 6   |
| 3.1.1 | Testing                    | 7   |
| 4.0   | Parts                      | 8-9 |



## **Kit Components**

| K-B13FXX001 AIR BRAKE KIT, FRONT (R1130) |                                       |     |  |  |  |
|--|---------------------------------------|-----|--|--|--|
| Part #                                   | Description                           | Qty |  |  |  |
| R-11076A                                 | Operating Valve Assembly              | 1   |  |  |  |
| R-19035                                  | Air Brake Hose                        | 1   |  |  |  |
| R-19039                                  | Air Brake Hose                        | 1   |  |  |  |
| R-19033                                  | 90 Degree Elbow, Male Flare X 3/8 NPT | 2   |  |  |  |
| R-32030D                                 | Brake Assembly, Drivers Side          | 1   |  |  |  |
| R-32030P                                 | Brake Assembly, Passengers Side       | 1   |  |  |  |
| R-32075D                                 | Rail Sweep Assembly, Drivers Side     | 1   |  |  |  |
| R-32075P                                 | Rail Sweep Assembly, Passengers Side  | 1   |  |  |  |
| R-32078                                  | SPACER                                | 2   |  |  |  |
| R-32052C                                 | MTG BLOCK                             | 2   |  |  |  |
| R-990KIT-396                             | MTG HARDWARE KIT                      | 1   |  |  |  |
| K-R11BXVX002B                            | Air Brake Control Kit                 | 1   |  |  |  |

## 1.0 General Information

An Air Toggle Valve will need to be installed in the instrument panel of the vehicle. This valve disconnects the railgear brake system when not in use.

On the Front Valve plate assembly and rear frame bracket, a relay valve will be located. The control line feeding this relay valve comes from the control valve described above. The supply line to this relay valve comes from the check valve screwed into the air reservoir. There is a ball valve and a pressure regulator inline between the check valve and relay valve. The ball valve will disconnect the railgear brake system from the vehicle air system regardless of the position of the air toggle valve. The pressure regulator will allow adjustment of the front to rear bias, so that both axles will brake evenly and not allow one axle to lock and slide.

The railgear Cobra Brake Assembly brake chambers are connected to the delivery ports on the railgear air relay valve.

Install airlines and valves as shown in Air Brake Schematic. Make certain that the front air brake pressure regulator is set to 75 PSI.


It is the responsibility of the installer to supply the required air to the in-cab control valve and from the in-cab control valve to the relay valve. The hoses, fittings etc... required for this connection are not included in this kit.




## 2.0 Installation

Note: The brakes should not be installed until the front railgear unit has been installed.

- 1. Clean and prep the axle stubs, in the area indicated, for welding.
- 2. Place brake assembly on stub axle and adjust as shown. Tack weld mounting block to stub axle.
- 3. Remove brake assembly from mounting block. Weld complete, the mounting block to the stub axle
- 4. Re assemble brake housing to mounting block.
- 5. Repeat steps 1 thru 4 for other brake assembly.
- 6. Proceed to plumb brakes as shown.
- 7. Adjust and test brakes as outlined.







Front Brake Pneumatic Schematic



#### 3.0

## **Brake Shoe Adjustment**

1. The is a jam nut and clevis located on the threaded rod attached to the air brake chamber. This is use to adjust the gap between the wheel and brake shoe.

## 3.1.1


## **Brake Testing**

Operate the vehicle on a test track. With the air toggle valve in the "on" position and the ball valves open, check that:

- 1. When the vehicle brake pedal is depressed, the railgear brake clamps the rail wheel enough to slow its rotation but not enough to stop its rotation. The rail wheels should not be allowed to lock up.
- 2. That the brakes release properly when the pedal is released.

If the brakes do not function properly, contact a service representative at G&B Specialties.







4.0 Parts

