

INSTALLATION OF R-290 HYDRAULIC KIT IN-CAB-CONTROLS (ICC) FRONT OR REAR PUMP/ MANIFOLD LOCATION FORD F-250/350, GM 2500HD/3500HD, & RAM 2500/3500

INSTALLATION SAFETY PRECAUTIONS

If any installation problems are encountered, please call G&B Specialties for technical assistance before continuing with the installation process.



- Failure to heed to any of the following warnings could result in severe bodily injury and/or equipment damage.
- Read and understand this manual completely before attempting installation or operation of the equipment.
- Installation/Operation instructions provided below only address the Rafna railgear equipment. Applicable railway company procedures and policies must be adhered to.
- Before performing any work under the vehicle or railgear, ensure the engine is turned off and the parking brake is set.
- When routing hydraulic hoses, ensure that the hoses do not contact any sharp edges or hot surfaces.
- When routing electrical wires, ensure that the wires do not contact any sharp edges or hot surfaces.
- All wire connections are to be soldered and heat shrink sealed to prevent future corrosion related problems.
- All wires must be covered with protective cable loom.
- Railway company rules governing rail travel must always be observed.
- Ensure all body parts and loose clothing are clear of any moving parts of the railgear. Be aware of all pinch points.
- Note that if the railgear is part way retracted or extended, opening the manifold directional valve manual over-rides may cause the railgear to drop suddenly causing personal injury. Ensure all body parts are clear of the railgear if it should suddenly drop.
- When operating the railgear using the emergency hand pump, ensure that the correct manual valve over-ride is open for the desired railgear (front or rear) and desired direction of operation (raise or lower).

- Do not use the emergency hand pump to raise and lower the railgear on a routine basis. If the hydraulic pump or manifold should fail, have it repaired as soon as possible.
- If the emergency hand pump has been used to raise or lower the railgear, ensure the manifold directional valve manual over-rides are in the closed and locked position before starting road or rail travel.
- Ensure the hydraulic pump has been de-energized before starting road or rail travel.

INSTALLATION OF HYDRAULIC KIT (ICC)

The following procedure details the installation of the hydraulic kit. The hardware required for this installation is listed in Table 1:

Table 1: Hydraulic Kit Installation Parts

Part Number	Description	Qty
R-2965	Pump Mounting Bracket	1
R-2965B	Front Pump Mounting Spacer	2
R-2965C	Manifold Mounting Plate	1
R-2965D	Pump Shim Plate	1
R-048	Hydraulic Pump and Manifold	1
R-700	In-Cab Control Panel	1
CO-071	10 Amp Circuit Breaker	1
CO-130N	"Front Gear Up" Decal	1
CO-130O	"Rear Gear Up" Decal	1
CO-130P	"Front Gear Down" Decal	1
CO-130Q	"Rear Gear Down" Decal	1
R-2868	Locking Cable Holding Collar	1
R-2961	In-Cab Control Lock Cam Converter	2
S-001031	Railgear Operation Decal	2
H-990KIT-000	1/4" Male O-Ring Boss to 1/4" Male JIC 90°	7
	3/8" Male O-Ring Boss to 1/4" Male JIC 90°	3
	3/8" Male O-Ring Boss to 1/4" Male JIC Straight	4
	Hose 16" Long	2
	Hose 23" Long	2
	Hose 33" Long	2
	Hose 360" Long	2
	1/4" Female JIC Straight Coupler (On Hoses)	12
	1/4" Female JIC 90° Coupler (On Hoses)	3
R-990KIT-011	1/4" UNC Gr. 8 Bolt x 1" Long	3
	1/4" SAE Washer	3
	1/4" Lock Washer	3
	5/16" UNC Gr. 8 Bolt x 1" Long	4
	5/16" SAE Washer	4
	5/16" Lock Washer	4
H-990KIT-052	Hydraulic Adapters	2
S-002002	Single Pilot Operated Check Valve	2
Not Supplied	2 & 14 Gauge Wire, Terminals, Loom, Etc.	-

1. If not already done, install the lock cam converters. Manually rotate both the front and rear railgear until the rail position lock cams are accessible. Position the lock cam converters on the rail position lock cams and weld them in place. Grind the cams smooth. The lock cam converters should prevent the front and rear lock pins from engaging in the rail position.

2. The pump is shipped with a manifold, a hand pump handle, a solenoid, and a rubber terminal boot.
3. Locate and install the solenoid in a convenient location under the hood near the vehicle's battery using installer supplied hardware. Ensure that the solenoid's body is electrically grounded.
4. Install the hydraulic fittings, adapters and hoses as shown on the hydraulic schematic.
5. There are four directional valve manual over-rides on the top face of the manifold. The decal plates can be installed on the top face of the manifold. Apply the decal plates next to the respective over-rides such that they are properly oriented while standing in front of the vehicle.
6. Ensure that none of the hoses contact any sharp edges or hot surfaces. Tie-wrap all hoses securely leaving enough slack for the railgear to function.
7. Install the In-Cab Control panel in the cab in a convenient location under the dash.
8. Install the circuit breaker under the hood near the previously installed railgear pump solenoid.
9. The pump manifold has three wire harnesses and two wires connected to it:
 - a) One 4' wire harness for the railgear with a control box closest to the pump.
 - b) One 36' wire harness for the railgear with a control box furthest from the pump.
 - c) One 22' wire harness for the in-cab controls with terminated wires on the end.
 - d) One white and one black wire each with ring terminals on the ends.
10. Using suitable 14 gauge wire, cable loom, connectors, solder and heat shrink tubing:
 - a) Lengthen the white wire if required and connect it from the manifold to the switching terminal on the railgear pump solenoid previously mounted under the hood.
 - b) Lengthen the black wire if required and connect from the manifold through the firewall to the load terminal on the railgear switch on the In-Cab Control panel.
 - c) Connect another length of black wire from the power terminal on the railgear to ignition activated power supply.
 - d) Connect another wire from the ground terminal on the railgear switch to a suitable ground location on the vehicle.
 - e) Ensure the manifold is properly grounded to the vehicle chassis by connecting a wire from the manifold to a suitable ground location on the vehicle. The railgear may not be properly grounded due to paint on the mounting plates and tar on the frame.


11. Using suitable 2 gauge wire, cable loom, connectors, solder and heat shrink tubing:
 - a) Connect one wire from the vehicle's battery to the circuit breaker. Then from the circuit breaker to the power terminal on the railgear pump solenoid.
 - b) Connect another wire from the load terminal on the solenoid to the power terminal on the pump motor. Use the supplied rubber boot to protect the pump power terminal from shorting out.
 - c) Ensure the pump motor base is properly grounded to the vehicle chassis by connecting a wire from the pump motor base to a suitable ground location on the vehicle. The railgear may not be properly grounded due to paint on the mounting plates or tar on the frame.
 - d) Route the 22' wire harness from the manifold through the firewall to the In-Cab Control panel. Connect the wires to the In-Cab Control switches as shown.
12. Route the 36' wire harness from the pump along the frame towards the opposite end of where the pump is mounted on the vehicle and secure in place with tie-wraps. If necessary, the control box can be removed from and reinstalled on the wire harness to facilitate routing. Fabricate a bracket and mount the railgear control box with installer-supplied hardware in a protected vertical position in a suitable location. Ensure the control box is within reach of the railgear locking cable handle.
13. Route the 4' wire harness from the pump towards the same end of the vehicle and secure in place with tie-wraps. If necessary, the control box can be removed from and reinstalled on the wire harness to facilitate routing. Fabricate a bracket and mount the front railgear control box with installer-supplied hardware in a protected vertical position in a suitable location. Ensure the control box is within reach of the railgear locking cable handle.
14. Ensure that the control boxes are mounted vertically so that the controls do not fill with water and freeze. They should also be mounted in a location protected from road spray etc.
15. Affix the supplied railgear operation decals in a suitable location adjacent to the front and rear control boxes.
16. Ensure all wires and terminals are soldered, heat shrink sealed, enclosed in protective cable loom and secured with tie-wraps.
17. Ensure all holes in the firewall are sealed and protected with a grommet.

18. Fill the hydraulic system and bleed the air out:
 - a) Fill the pump tank with **DEXRON III** (or equivalent) hydraulic fluid.
 - b) Operate the front railgear up and down briefly to circulate the fluid and bleed the system of air (refer to the Railgear Kit and Hydraulic Kit Operation, Service, and Parts manuals for operation instructions).
 - c) Refill the pump tank and repeat the above step until all air is removed from the front hydraulic system.
 - d) Operate the rear railgear up and down briefly to circulate the fluid and bleed the system of air (refer to the Railgear Kit and Hydraulic Kit Operation, Service, and Parts manuals for operation instructions).
 - e) Refill the pump tank and repeat the above step until all air is removed from the rear hydraulic system.
 - f) With both front and rear railgear locked in the road position, fill the pump tank to the full line.
19. Follow the Hydraulic System Relief Valve Setting procedure detailed in the Hydraulic Kit Service section of this manual
20. Test the fit of the locking cable holding collar on both the front and rear locking cables. Ensure that the locking cable holding collar keeps the railgear locking pin fully disengaged. Grind the locking cable holding collar or adjust the locking cable handle on the cable to fit if necessary.
21. Test the operation of the controls and directional valve manual over-rides. Refer to the operation procedure in the Railgear Kit Manual and Hydraulic Kit Operation section of this manual.
22. Lower both front and rear railgear to rail position and ensure the lock cam converters previously installed prevent the lock pins from engaging the lock cams.
23. Locate and store the hand pump handle and the locking cable holding collar in a secure location in the vehicle cab.

Ensure that the thermal overload wires are properly spliced/connected as shown

It is recommended that a 200 amp fuse or 200 amp Circuit Breaker be installed to isolate the hydraulic pump from the vehicle electrical system as shown

PARTS LIST			
ITEM	PART NUMBER	DESCRIPTION	QTY
1	R-2920	FRAME, LOWER CROSS	1
2	R-2961	CONVERTER, ICC LOCK CAM	1



NOTES

1. WELD CAM TO LOWER CROSS FRAME AND GRIND FLUSH


REVISION	DATE	BY	APPRVD	ECN #	JMP SMM	JMP SMM
A	05/17/21	SMM				
<p>REVISION DESCRIPTION OF CHANGES</p> <p>A. REVISION A RELEASED</p>						
<p>DESIGN - ENGINEERING - MANUFACTURING</p> <p>ICC LOCK CAM INSTALL</p>						
<p>ALL WELDS TO CONFORM TO AWS D1.1</p>						


G & B SPECIALTIES INC.
MANUFACTURER OF QUALITY RAILROAD PRODUCTS
BERWICK, PENNSYLVANIA (570) 752-5901, FAX (570) 752-6397

DESIGN - ENGINEERING - MANUFACTURING

ICC LOCK CAM INSTALL

1 K-H29RRGR048003-LC 05/17/21 K-H29RRGR048003-LC A







MIO-H29RRGR048003 REV J

ITEM	PART NO.	DESCRIPTION	QTY
1	R-048	ELECTRIC HYDRAULIC PUMP W/ MANIFOLD	1
2	S-002002	SINGLE P.O. CHECK VALVE	2
3	848FSO-04x06	3/8" MALE O-RING BOSS TO 1/4" MALE JIC	4
4	849FSO-04-04	1/4" MALE O-RING BOSS TO 1/4" MALE JIC 90°	3
5	849FSO-04-06	3/8" MALE O-RING BOSS TO 1/4" MALE JIC 90°	3
6	HU-04-04NJ	1/4" FEMALE JIC STRAIGHT COUPLER	12
7	HU-04-04NJ90T	1/4" FEMALE JIC 90° COUPLER	4
8	HFS2-04	HOSE 16" LONG	2
9	HFS2-04	HOSE 23" LONG	2
10	HFS2-04	HOSE 33" LONG	2
11	HFS2-04	HOSE 360" LONG	2
12	C5216x4x6	1/4 JIC FEMALE X 3/8 MALE O-RING	2
13	848FSO-04x04	1/4" MALE O-RING BOSS TO 1/4" MALE JIC	4
14	848FSO-04x06	3/8" MALE O-RING BOSS TO 1/4" MALE JIC	(2)*
15	897-FS-04	1/4" JIC FEMALE x 1/4" JIC MALE, 90° SWIVEL	(2)*
16	R-9115	HYDRAULIC CYLINDER ASSEMBLY	(2)
17	R-2965B	PLATE PUMP MOUNTING	2
18	R-2965C	MANIFOLD MOUNTING PLATE	1

DESCRIPTION OF CHANGES		DATE	BY	APPROVD	ECN #	APL	REV
A	REVISION A RELEASED	10/10/14	AML			APPROVED	1
C	UPDATED BORDER	05/17/21	SMI	JMP		CHECKED	1

G & B SPECIALTIES INC.
 MANUFACTURER OF QUALITY RAILROAD PRODUCTS
 BERWICK, PENNSYLVANIA (910) 752-5801 / FAX (910) 752-6387



R-290 ICC R-048
ELECTRICAL PUMP
INSTALLATION BOM

DESIGN - ENGINEERING - MANUFACTURING

Q & B SPECIALTIES INC. IS THE OWNER OF THIS
 DRAWING. IT IS TO BE USED ONLY FOR THE
 PROJECT SPECIFICALLY IDENTIFIED HEREIN. IT IS
 NOT TO BE REPRODUCED OR COPIED IN ANY
 FORM OR BY ANY MEANS, WITHOUT THE
 WRITTEN PERMISSION OF G & B SPECIALTIES
 INC. ANY VIOLATION OF THIS POLICY WILL
 BE PROSECUTED TO THE FULL EXTENT OF
 THE LAW.

REVISION C


1 EXXXXXR048

10/10/14

REVISION C

G&B Specialties Inc. 535 West 3rd Street, Berwick, PA, USA Tel: (570) 752-5901 Fax: (570) 752-6397
US Field Service: 570-441-6988; CAN Field Service 570-854-0482; www.rafna.com

MOUNT PUMP AND MANIFOLD USING SUPPLIED BRACKETS OR FABRICATE YOUR OWN. BRACKETS WILL NEED TO BE WELDED TO RAILGEAR AT LOCATIONS CHOSEN BY INSTALLER. CHOOSE A LOCATION ON FRONT OF VEHICLE WHICH WILL ACCOMMODATE YOUR END USERS REQUIREMENTS. PHOTOS ARE ATTACHED FOR REFERENCE USE ONLY.




SUPPLIED PARTS, R-2965, R-2965B, AND R-2965C





MIO-H29RRGR048003 REV J





- 1- ALL CONNECTIONS TO BE SOLDERED AND HEAT SHRINK SEALED
- 2- ENSURE ALL WIRES ARE SECURED AWAY FROM HEAT AND SHARP EDGES






ITEM	PART NO.	DESCRIPTION	QTY
1	R-048	ELECTRIC HYDRAULIC PUMP W/ MANIFOLD	1
2	S-002002	SINGLE P.O. CHECK VALVE	2
3	848FSO-04x06	3/8" MALE O-RING BOSS TO 1/4" MALE JIC	4
4	849FSO-04-04	1/4" MALE O-RING BOSS TO 1/4" MALE JIC 90°	3
5	849FSO-04-06	3/8" MALE O-RING BOSS TO 1/4" MALE JIC 90°	3
6	HU-04-04NU	1/4" FEMALE JIC STRAIGHT COUPLER	12
7	HU-04-04NJ90T	1/4" FEMALE JIC 90° COUPLER	4
8	HFS2-04	HOSE 16" LONG	2
9	HFS2-04	HOSE 23" LONG	2
10	HFS2-04	HOSE 33" LONG	2
11	HFS2-04	HOSE 360" LONG	2
12	C5216x4x6	1/4 JIC FEMALE X 3/8 MALE O-RING	2
13	848FSO-04x04	1/4" MALE O-RING BOSS TO 1/4" MALE JIC	4
14	848FSO-04x06	3/8" MALE O-RING BOSS TO 1/4" MALE JIC	(2)*
15	897-FS-04	1/4" JIC FEMALE x 1/4" JIC MALE, 90° SWIVEL	(2)*
16	R-9115	HYDRAULIC CYLINDER ASSEMBLY	(2)
17	R-2965B	PLATE PUMP MOUNTING	2
18	R-2965C	MANIFOLD MOUNTING PLATE	1


 G & B SPECIALTIES INC. MANUFACTURER OF QUALITY MARINE PRODUCTS BERWICK, PENNSYLVANIA (570) 752-5901 FAX (570) 752-6397		DESIGN - ENGINEERING - MANUFACTURING		R-2965C R-048 EXPLANATION BOM		REVISION	
A REVISION A RELEASED C UPDATED BORDER		DATE 10/10/14 05/17/21		BY AMIL SNM		APPROVD JMP	
DESCRIPTION OF CHANGES		ECN #		CHECKED		DATE DRAWN	
1 EXXXXXR048		10/10/14		EXXXXXR048		C	

R-048 REAR MOUNTED INSTALLATION



PARTS LIST			
ITEM	PART NUMBER	DESCRIPTION	QTY
1	R-048	HYDRAULIC PUMP AND MANIFOLD	1
2	R2965	PUMP MOUNTING BRACKET	1
3	R2965D	PUMP MOUNTING SPACER	1
4	R-2868	LOCKING CABLE HOLDING COLLAR	1
5	CO-130N	"FRONT GEAR UP" DECAL	1
6	CO-130O	"REAR GEAR UP" DECAL	1
7	CO-130P	"FRONT GEAR DOWN" DECAL	1
8	CO-130Q	"REAR GEAR DOWN" DECAL	1
9	S-001031	RAILGEAR OPERATION DECAL (NOT SHOWN)	2
10	R-990KIT-011	1/4" UNC GR.8 BOLT X 1" LONG	3
11		1/4" GR.8 LOCK WASHER	3
12		1/4" GR.8 WASHER	3
13		5/16" UNC GR.8 BOLT X 1" LONG	4
14		5/16" GR.8 LOCK WASHER	4
15	R-990KIT-011	5/16" GR.8 WASHER	4
16	-	RAILGEAR MOUNTING BRACKET (AS PER REARGEAR KIT)	N/A
17	-	RAILGEAR LOCK CABLE (AS PER RAILGEAR KIT)	N/A

REV	DESCRIPTION OF CHANGES	DATE	BY	APPRVD	ECN #	DRAWN	MFR
A	REVISED DRAWING AND BORDER	08/09/19	AJB				



G & B SPECIALTIES INC.
 MANUFACTURER OF QUALITY RAILROAD PRODUCTS
 BERWICK, PENNSYLVANIA (870) 762-5801, FAX (870) 762-8387

DESIGN - ENGINEERING - MANUFACTURING

G & B SPECIALTIES INC. IS THE OWNER OF THIS DRAWING. IT IS TO BE USED ONLY FOR THE PURPOSES OF THE CONTRACT FOR WHICH IT WAS PREPARED. NO PARTS OF THIS DRAWING ARE TO BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS, ELECTRONIC OR MECHANICAL, INCLUDING PHOTOCOPYING, RECORDING, OR BY ANY INFORMATION STORAGE AND RETRIEVAL SYSTEM, WITHOUT THE WRITTEN PERMISSION OF G & B SPECIALTIES INC. THIS DRAWING IS NOT TO BE COPIED, REPRODUCED OR TRANSMITTED TO OTHERS, EXCEPT WITH THE WRITTEN PERMISSION OF G & B SPECIALTIES INC.

DESIGN - ENGINEERING - MANUFACTURING		R-290 HYDRAULIC KIT ICC	
BRIEF DRAWING NUMBER	DATE DRAWN	PART NUMBER	REVISION
1	K-H290RGR048003	06/23/04	K-H290RGR048003 A

OPERATION, SERVICE, AND PARTS OF R-290 HYDRAULIC KIT IN-CAB-CONTROLS (ICC) FRONT OR REAR PUMP/ MANIFOLD LOCATION FORD F-250/350, GM 2500HD/3500HD, & RAM 2500/3500

OPERATION AND SERVICE SAFETY PRECAUTIONS

If any operating, service or parts problems are encountered, please call G&B Specialties, Inc. for technical assistance.



- Failure to heed to any of the following warnings could result in severe bodily injury and/or equipment damage.
- Read and understand this manual completely before attempting operation of the railgear equipped vehicle.
- Operating instructions provided below only address the Rafna railgear equipment. Applicable railway company procedures and policies must be adhered to.
- Railway Company rules governing rail travel must be observed at all times.
- Before performing any work under the vehicle or railgear, ensure the engine is turned off and the parking brake is set.
- Ensure all body parts and loose clothing are clear of any moving parts of the railgear. Be aware of all pinch points.
- Note that if the railgear is part way retracted or extended, opening the manifold directional valve manual over-rides may cause the railgear to drop suddenly causing personal injury. Ensure all body parts are clear of the railgear if it should suddenly drop.
- When operating the railgear using the emergency hand pump, ensure that the correct manual valve over-ride is open for the desired railgear (front or rear) and desired direction of operation (raise or lower).
- Do not use the emergency hand pump to raise and lower the railgear on a routine basis. If the hydraulic pump or manifold should fail, have it repaired as soon as possible.
- If the emergency hand pump has been used to raise or lower the railgear, ensure the manifold directional valve manual over-rides are in the closed and locked position before starting road or rail travel.
- Ensure the hydraulic pump has been de-energized before starting road or rail travel.

OPERATION OF HYDRAULIC KIT (ICC)

With the hydraulic kit installed on this vehicle, it may be operated as normal.

Never operate the vehicle if the Gross Vehicle Weight Rating (GVWR), Gross Axle Weight Rating Front or Rear (GAWR), or the wheel or tire load ratings are exceeded.

Refer to the Railgear Kit Operation, Service and Parts manual for information on the mechanical operation, service and parts of the railgear.

LOCATION AND OPERATION OF THE RAILGEAR HYDRAULIC SYSTEM CONTROLS

The railgear hydraulic system consists of a hydraulic pump and manifold, a front control box and a rear control box.

1. The railgear hydraulic pump must be energized prior to use by turning on the respective dash switch. At this point the dash switch light should come on but the pump should not run and the railgear should not move until a control button is depressed.
2. The direction of the front or rear railgear movement is selected by pushing the “Up” or “Down” button on the respective control box located near the railgear. At this point the pump should start and the railgear should move in the selected direction.
3. To stop the movement of the railgear, release the depressed button.
4. The pump must be de-energized after use by turning off the respective dash switch. At this point the pump should not be able to run and the control buttons should be inactive.

LOCATION AND OPERATION OF THE HYDRAULIC PUMP EMERGENCY HAND PUMP

If the railgear hydraulic system should fail such that the railgear does not respond to depressing the buttons on the front and / or rear control boxes, then the emergency hand pump system may be used to place the vehicle on rail or remove the vehicle from rail. Follow the standard operation procedure (as detailed in the Railgear Kit Operation, Service and Parts Manual) except substitute the following steps when the procedure requires raising or lowering of the railgear.

1. Remove the hand pump handle from storage and insert the handle into the hand pump located on the body of the hydraulic pump.
2. There are four manifold directional valves, one for each railgear function: “Front Gear Up”, “Front Gear Down”, “Rear Gear Up”, and “Rear Gear Down”. The manual over-rides for these valves are located on the manifold under rubber boots. Only open one manifold directional valve over-ride at a time. To manually open a manifold directional valve over-ride, remove the rubber boot, push in and twist the knob counter clockwise allowing the knob to extend. To manually close a manifold directional valve over-ride, push the knob in, twist the knob clockwise to lock it in place and replace the rubber boot.

3. Select and open the manual over-ride for the respective railgear and desired direction of movement.
4. Remove the locking cable holding collar from storage. It can be slipped in between the locking cable handle and the locking cable bulkhead fitting to hold the locking cable in the disengaged position.
5. Pump the emergency hand pump handle to move the railgear. It will require approximately 100 full strokes to fully raise or lower each railgear.
6. Close the manual over-ride. Ensure all manifold directional valve manual over-rides are closed and locked in position. Replace all the rubber boots.
7. Remove and store the locking cable holding collar and the hand pump handle.
8. Ensure the railgear lock pins are fully engaged as required by the procedure.

SERVICE OF HYDRAULIC KIT

The hydraulic kit must be serviced regularly to avoid damage to the equipment.

The recommended oil for the railgear hydraulic system is **DEXRON III** or equivalent. In extremely cold weather areas/seasons, Tellus S4 VX32 or equivalent may be used.

Table 1: Recommended Service Schedule

Service Required	Initial 100 km (62 Miles) of road and/or rail use	Daily	Weekly	Monthly
Inspect hydraulic kit fasteners (re-torque if required)		✓	✓	✓
Inspect all hydraulic fittings and hoses for leaks and wear.		✓	✓	✓
Check oil in hydraulic reservoir. (fill with railgear raised if req'd)				✓
Check emergency hand pump and manifold over-ride operation				✓

HYDRAULIC SYSTEM RELIEF VALVE SETTING

This system is equipped with one relief valve located on the railgear pump body next to the emergency hand pump. This relief valve protects the entire hydraulic system from over pressurization. The relief valve will not require adjustment at installation. If ever there appears to be inadequate hydraulic pressure to operate the railgear, then the relief valve may need to be adjusted.

1. Disconnect the hydraulic hose from the “P” port of the pump.
2. Install a hydraulic pressure gauge (up to 3000 PSI) between the disconnected hydraulic hose and the pump port. The pressure gauge will indicate the relief valve setting when the pump is loaded.
3. Following the procedure in the Railgear Kit Operation, Service and Parts manual raise the front railgear completely and continue to raise the railgear so that the hydraulic cylinder creates a load on the pump by trying to “dead-head”. The pressure reading on the pressure gauge should climb to 1800 PSI.
4. If the pressure is not correct, release the railgear controls and adjust the relief valve on the pump accordingly. Loosen the lock nut and turn the setscrew in to increase the pressure or out to decrease the pressure. Re-check the pressure.
5. Once the correct pressure on the pump relief valve is obtained, ensure the lock nut on the relief valve is tightened. Release the pressure in the system and remove the pressure gauge. Re-connect all hydraulic hoses.
6. Ensure the railgear is properly raised as per the Railgear Kit Operation, Service and Parts manual.

ELECTRICAL SYSTEM TROUBLESHOOTING

The following basic test can be performed to check the integrity of the railgear electrical system.

Should the railgear pump fail to operate, first check the fuse or the circuit breaker and all wiring for shorts. Then the following test can be performed to verify the integrity of the pump motor and pump solenoid.


1. Pump motor test:
 - a) Connect one end of a 2 gauge shunt wire to the pump motor power terminal and touch the other end to the battery positive terminal.
 - b) The pump motor should run upon touching the shunt wire.
 - c) If the pump does not run, the pump is not properly grounded, or the pump motor is defective.
 - d) If the pump motor runs, test for a defective solenoid.
2. Solenoid test:
 - a) Connect one end of a 14 gauge shunt wire to the switching terminal on the solenoid and touch the other end to the battery positive terminal. If the pump does not operate the solenoid is not properly grounded or it is defective. If the pump operates, the problem lies with the fuse/circuit breaker, wiring and/or switches.

Should the pump start running immediately following turning on the respective dash switch, the following tests can be performed to help locate the problem.

1. Disconnect the wire from the switching terminal on the solenoid. If the pump continues to run, then the solenoid is defective.
2. Check all wiring and switches for shorts and / or loose terminals.


PARTS OF HYDRAULIC KIT

PARTS LIST			
ITEM	PART NUMBER	DESCRIPTION	QTY
1	S-309616	BREATHER	1
2	S-309608	RESERVOIR/TANK	1
3	S-309600	MOTOR	1
4	S-309607	CHECK VALVE	1
5	S-309605	HAND PUMP ASSEMBLY	1
6	S-309603	HAND PUMP BLOCK	1
7	S-309627	PUMP HANDLE	1
8	S-309617	OIL RETURN PIPE	2
9	S-309604	PUMP	1
10	S-309609	COUPLING	1
11	S-309618	HEX SOCKET BOLT	2
12	S-309610	SUCTION OIL PIPE	1
13	S-309611	FILTER	1
14	S-309612	MAGNET	1
15	S-309602	BODY VALVE BLOCK	1
16	S-309620	IRON PLUG	1
17	S-309619	HEX SOCKET BOLT	3
18	S-309615	HEX FLANGED SCREW	4




REV DESCRIPTION OF CHANGES		DATE	BY	APPRVD	EON #
A. REVISION A RELEASED		10/16/19	SMM	JMP	
B. REVISED PART NUMBERS		07/14/20	SMM	SMM	
G&B SPECIALTIES INC.		BERWICK, PENNSYLVANIA (570) 752-5901 FAX (570) 752-6397			
DESIGN - ENGINEERING - MANUFACTURING		R-048/R-048B PUMP PARTS			
JMP SMP		1 5003041			
JMP SMP		10/16/19 S-003041			
JMP SMP		B			

NOTES
1. TO BE USED WITH PUMPS HAVING SERIAL NUMBERS OF THE KS SERIES



PARTS LIST			
ITEM	PART NUMBER	DESCRIPTION	QTY
1	S-309601	SOLENOID	1
2	S-309624	TERMINAL BOOT	1



REV	DESCRIPTION OF CHANGES	DATE	BY	APPRVD	ECN #	DMVN
A	REVISION A RELEASED	10/18/19	SMI	JMP		JMP
						CHCKED
						JMP
						APPROVED



G & B SPECIALTIES INC.
 MANUFACTURER OF QUALITY RAILROAD PRODUCTS
 BERWICK, PENNSYLVANIA (717) 732-6367, FAX (717) 732-6367


DESIGN - ENGINEERING - MANUFACTURING

G & B SPECIALTIES INC. IS THE OWNER OF THIS DRAWING. IT IS TO BE USED ONLY FOR CONSTRUCTION PURPOSES ONLY, AND NOT BE REPRODUCED OR COPIED IN ANY MANNER WITHOUT THE WRITTEN CONSENT OF G & B SPECIALTIES INC. ANY CHANGES TO THIS DRAWING MUST BE MADE ON ITS CONTENTS, AND BEV TO BE COVERED BY A REVISION. ANY CHANGES TO THIS DRAWING MUST BE MADE ON ITS CONTENTS, AND BEV TO BE COVERED BY A REVISION.


R-048/R-048B
MISC. PARTS

1 MISCRO48B
1 MISCRO48B

DATE DRAWN 10/17/19
PART NUMBER MISCRO48B
REVISION A



BILL OF MATERIAL/PARTS LIST			
ITEM	QTY	PART NUMBER	DESCRIPTION
1	REF	R-9115	CYLINDER
2	REF	849FSO-04-06	Jic(-4) to Male O-ring (-6), 90 degrees
3*	2	C5216X4X6	1/4 JIC X 3/8 MALE ORB
4	2	S-002002	P.O. CHECK VALVE
5	REF	6400-4-6	3/8 MALE ORB x 1/4 JIC MALE ADAPTER
6	REF	6500-4-4	1/4 JIC FEMALE x 1/4 JIC MALE, 90 DEGREE



*REF: H-990KIT-052

NOTES:

1. ITEMS #2, #5 AND #6 INCLUDED WITH ITEM #1

REV/DESCRIPTION OF CHANGES	DATE	BY	APPRVD	ECN #	DRWN
A REVISION A RELEASED	09/23/13	JL			
B REVISED/ADDED ITEMS 5 & 6	04/09/15	AML	JL		
C UPDATED BORDER	05/17/21	SMM	JMP		

APPROVED	CHECKED	DESIGN - ENGINEERING - MANUFACTURING	SINGLE P.O. CHECK VALVE KIT	REVISION

ALL WELDS TO CONFORM TO AWS D1.1

1 R-9115POVAL 0923/13R-9115POVAL C